

## **GLIMMER ALARM INSTRUCTIONS**

### **Manual Power Switch**

**Power On** – Push the switch to the left

**Power and Nightlight On** – push the switch to the right

**Power Off** - push the switch back to the middle position

### **Volume Button**

Push the “V” button to change the volume between *Low, Medium, High, and Ultra-High*

### **Tone Button**

Push the “T” button to change the tone between *Low, Medium, High, and Ultra-High*

### **Sensitivity Button**

Push the “S” button to increase sensitivity. Press once for low sensitivity, again to increase the level of sensitivity; continue to press until the desired level of sensitivity is reached.

### **Power Out Socket**

Compatible with illuminated swingers and hangers

### **Latching LED**

LED latches (stays on) 20 seconds after bite/run has finished.

### **Memory Function**

The memory function stores your last settings (sensitivity, tone and volume)

### **DIP Switch System – Setting Up Alarms with Receiver**

There are 8 dip positions (up and down). The first 4 dips are used when setting up the wireless bite alarm head with the receiver.

Ensure you have the bite alarm head and the receiver dip switches in the same position (they need to match each other’s position, in pairs).

The last 4 dips are used to indicate what colour LED you want displayed on the receiver when the bite alarm head is activated:

DIP 5 up – RED

DIP 6 up – Green

DIP 7 up – Yellow

DIP 8 up – Blue

### **Wireless Receiver**

### **Manual on/off button**

Moving the switch to the central position (0) turns the receiver off.

### **Volume Control / Vibration Button**

Push the + button to increase volume.

Push the – button to decrease volume.

***IMPORTANT*** – *There are 4 DIP switches to ensure your receiver is tuned into your bite alarm head; ensure that these DIP switches in the receiver correspond with the positions of the DIP switches in your alarm head(s).*